


MULTICUT 08

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①	Kondensator	Capacitor	JP46016
②	Schalterschütz	Contactora	JP46056
③	Mikroschalter	Microswitch	
	230 V		JP46351
	400 V		JP46352
④	Haube	Top cover	
	MS, MES		JP46018
	M, ME		JP46019
⑤	Schwimmer	Float	JP46022
⑥	Schaltwelle	Switch shaft	JP46020
⑦	Schalterpatrone	Switch cartridge	JP46025
⑧	Leitung	Cable	
	230 V		JP42777
	400 V		JP42779
	with A/NZ plug (230V)		JP47221
⑨	Lagersatz	Bearing set	JP46042
⑩	Passscheiben	Shim rings	JP46559
⑪	Rotorwelle	Rotor Shaft	
	230 V		JP46551
	400 V		JP46552
⑫	Stator + Gehäuse	Stator + housing	
	230 V		JP46029
	400 V		JP46030
⑬	Dichtungssatz	Seal set	JP46041
⑭	Lauftrad	Impeller	
	M		JP45467
	60 Hz		JP46555
	ME		JP46556
⑮	Pumpengehäuse mit Schleißplatte	Pump casing with wear plate	JP46553
⑯	Ölschraube	Oil screw	JP46046
⑰	Gleitringdichtung	Mechanical seal	JP46043
⑱	Standfüße	Pump pedestal	JP44759
⑲	Schneidplatte	Cutter plate	JP45470
⑳	Schraubensatz	Screw set	JP46560
㉑	Schneidrotor	Cutter	JP45472
㉒	Schleißplatte	Wear plate	JP46557
㉓	1l Öl	1l Oil	JP48236

a	10x Scheibe / Shim ring 12x16x0,2	JP48114
b	10x Scheibe / Shim ring 12x30x0,1	JP48082
	10x Scheibe / Shim ring 12x30x0,2	JP48083
	10x Scheibe / Shim ring 12x30x0,3	JP48084
c	10x O-Ring 10x2,5	JP48088