



COMPLI 400

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



① Pumpe	Pump	
Compli 400		JP50469
Compli 400, 15M		JP50162
Compli 400 E		JP50470
Compli 400 E, 15M		JP50584
② Adapter DN100/80		JP50478
③ Elast. Verbindung	Elastic connector	JP50905
④ Steuerung	Control unit	
AD 00R (Compli 400)		JP50708
AD 69ECR (Compli 400 E)		JP50720
⑤ Pumpenaufnahme	Mounting ring pump	JP50477
⑥ Flansch	Flange	JP43706
⑦ Steuerungsplatine	Control board	
PCBA AD 00 (Compli 400)		JP50497
PCBA AD 69EC (Compli 400 E)		JP50501
⑧ Niveauerfassung 4,0 m	Level controller 4,0 m	JP50467
Niveauerfassung 15,0 m	Level controller 15,0 m	JP50468
⑨ Rückschlagklappe	Reflux valve	JP43707
⑩ Zulauf	Inlet	JP50472
⑪ Montageset Pumpe	Pump assembly kid	JP49001
⑫ Dichtung Niveauerf.	Spare seal level control	JP50479
⑬ Wartungsdeckel	Service lid	JP42798
⑭ Montagering RSK	Mounting ring RV	JP50476
⑮ Dichtungen Drucks.	Seals discharge	JP50481
⑯ Dichtungen Hydr.	Seals hydraulic	JP50480
⑰ Überschiebmuffe	Collar	JP47287
⑱ Pumpenlüftung	Pump ventilation	JP43710
⑲ Steckdichtung	Plug in seal	JP45099
⑳ Auftriebssichg.	Anti floating	JP50473
⑳ Behälter (inkl. Pos 10)	Tank (incl. pos. 10)	JP50474

PENTAIR JUNG PUMPEN
MOTOR COMPLI 400 GB



① Leitung	Cable	
compli 400	10/4 BW	JP50485
	10/4 BW, 15 m	JP50161
compli 400 E	10/4 BWE, 4m	JP50486
	10/4 BWE, 15m	JP50487
② Stator + Gehäuse	Stator + Housing	
compli 400		JP50488
compli 400 E		JP50448
③ Lagersatz	Bearing set	JP46724
④ Motorabdichtung	Motor seals	JP46806
⑤ Rotorwelle	Rotor shaft	
compli 400		JP46761
compli 400 E		JP46801
⑥ Schraubensatz	Screw set	JP50450
⑦ Lagerschild	Bearing housing	JP43720
⑧ Dichtungssatz	Seal set	JP50449
⑨ Laufradschraube	Impeller screw	JP46803
⑩ Laufrad	Impeller	
UC 10/4		JP47290
UC 15/4		JP50320
UC 25/4		JP50321